



Attorney Docket No.: VNI-018

IN THE UNITED STATES PATENT AND TRADEMARK OFFICE

In Re Application of: Pickett et al.) Notice of Allow. Mailed: August 1, 2002
Serial No.: 09/849,326)
Filed: May 4, 2001) Examiner: Vincent, D.
For: Systems and Methods for Multiple Mode Voice and Data Communications Using Intelligently Bridged TDM and Packet Buses and Methods for Performing Telephony and Data Functions Using the Same	Group Art Unit: 2661))
Commissioner of Patents and Trademarks Washington, D.C. 20231	
ATTENTION: Official Draftsperson	

TRANSMITTAL OF FORMAL DRAWINGS

Applicant hereby submits <u>SEVENY-SEVEN</u> (<u>1717</u>) sheets of Formal drawings for filing in the above-identified application. A Notice of Allowance was mailed <u>August 1, 2002</u>, and the issue fee payment is being submitted concurrently herewith.

Respectfully submitted

Alan R. Loudermilk
Attorney for Applicant(s)

Registration No.: 32,788

Los Altos, CA 94024-0607


(408) 868-1517

CERTIFICATE OF MAILING

I hereby certify that the foregoing is being deposited with the U.S. Postal Service, postage prepaid, to Box Issue Fee, Assistant Commissioner for Patents, Washington, DC 20231 this Leday of Move, 2002.

Man R. Loudermilk











FIG. 2










FIG. 3A






FIG. 4






FIG. 5






FIG. 6




FIG. 7







FIG. 7A










FIG. 8B






FIG. 8C






FIG. 8D







FIG. 9A





- 208

FIG. 9B






FIG. 9C






FIG. 10A









FIG. 10B






















FIG. 12






FIG. 13A




FIG. 13B




FIG. 13C






FIG. 14



InstantOffice Remote Managemen	nt Console
Log Off	Diagnostics Help
General Administration	
Chassis View Password Administration	Access Permissions
General Settings 📾 SNMP Configuration 🗔	SNMP Alarms
🔚 Software Versions 🕠 System Backup/Restore	Software Upgrade
Call Detail Report Separation	Date and Time
Restart InstantOffice	
PBX, Voice Mail, and CTI Administration	
Extension Configuration Hunt Groups	Local TAPI Configuration
AutoAttendant & Voice Mail Station Ports	CTI Speed Dial No.
First Digit Table	
Data Administration	
IP Network Settings	
IPX Configuration Network Services & Adapters	
Trunk Administration	
Trunk Groups Finance Trunk Access Profiles	Frame Relay
T-1 Trunks Analog Trunks	

FIG. 15






FIG. 16A

T-1 Trunks	F				
Card/Module: [(Slot 14) 1-1 Module, 2-Port Port 1 Port 2	D				
Trunk Settings	Chann	Channel Settings			
Trunk in Service		ISDN	None	ne 🔻	- 1-1
		Enabled	Signaling	Trunk Groups	
ınk Type	÷-	Yes	Wink Start	DID Digital	
	- - - - - -	X S	Ground Start	Voice Analog	
- ISDN Switch Variant	4,	Yes	Wink Start	Voice Digital	7
AT&T	٠ ٠	% & &	Wink Start	WW Nate	
	-7-	No	Wink Start	None	
System Clock Reference		No.	Wink Start	None	
Not Used □	*=	0 'S	Wink Start	None	
, t	11-	S o	Wink Start	None	
Framing	-12-	%;	Wink Start	None	_
ESF	÷ 4	22	Wink Start	None	
- Line Coding	-15-	No	Wink Start	None	-
I B87S	9-	oN;	Wink Start	None	
	÷ ==	22	Wink Start	None	
	-61-	No	Wink Start	None	
7.5db	-50-	No	Wink Start	None	
	-21-	So.	Wink Start	None	
(e) Courteey Peset OForce Decet	-22-	2 2	Wink Start	None	
Comitos) reser (10100 reser	-23-	No No	Wink Start	None	

FIG. 16B

State State Phone Type -1- Enabled -2- Enabled -3- Enabled -4- Enabled -6- Enabled -1- Enabled -1- Enabled Basic -1-	<u> </u>	Operation Mode	Station	Station	Station	Station	Vmail	Station	No Config	Station	Vmail	Station		Help														
State Enabled	☐ Card in Service		Stutter	Stutter	Lamp	Stutter	Stutter	Stutter	Lamp	Stutter	Stutter	Stutter	Stutter	Stutter	Stutter	Stutter	Stutter	Stutter	Stutter	Stutter								
	▶	Phone Type	Caller ID	Basic	Basic	Caller ID	Basic	Basic	Basic	Basic	Basic	Basic	Basic	Basic	Basic	Basic	Basic											
		State				┙		_]														ᆚ						

FIG. 16C



Analog Trunk Configuration	
Card/Module: None ▼	
Port Parameters — Trunk Group — ▼	
Port Settings —	
Enabled Signaling Trunk Group	
□ Courtesy Reset Default	
Restore Apply Done H	elp

FIG. 16D



Frame Relay Co	onfiguratio	n	
Virtual Port		▼ □ Removed	Add
Name:			
DLCI (16	-991)	100	
LMI Mod	le:	User	▼
LMI Type	e:	T1.617 Annex D	•
Encapsula	ation:	RFC1490	•
Res	store	Apply Don	e Help

₃₈₆ – J

FIG. 16E



Network Settings
Host Name — Domain Name — vertical.com
Network Interface: [1] Resource Switch Card: 10BT Ethernet ▼
IP Address DNS WINS
Windows Internet Name Services (WINS)
Primary WINS Server: Secondary WINS Server:
☐ Enable DNS for Windows Resolution
Scope ID:
Restore Apply Done Help

388 /

FIG. 16F



InstantOffice D	Diagnostic Tools	
Log Off □ Log Off □ □		TBO [?] Help
Diagnostic Tools		•
. Ping	Netstat	Trace Route
ARP	Host Name	IP Config
Route Print	를 Link Monitor	Station Monitor
Trunk Monitor	Voice Mail Monitor	Trace Monitor
TBO Windows NT Diagnostics E Event Viewer	Performance Monitor Network Monitor	TBO Task Manager

FIG. 17A



			_	_	<u>. T</u>			_	_		_		_				_	_								_	_		_
M			<u> </u>	<	1	_		,		_			┙		_	_		1		_	_			_		\perp	\triangleright		
	(in secs): [1		Calling Party	300	301	302	303	304	305	306	8481307	8481308	8481309	8481310	8481311	8481312	8481313	8481314	8481314	8481314	8481314	8481314	8481314	8481314	8481314	8481314	8481314		
	Polling Intervals (in secs):	Refresh	Called Party																										
																:													
	Polling	emand	State	Incoming Call	Outbound Call		Outbound Call		Outbound Call	Outbound Call	Outbound Call	Done																	
	O Use Periodic Polling	Refresh On Demand	Port	3	3	3	8	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	De	
													(,		. 3			(,,	C 3	(2)	~)		(2)		<u> </u>		3		
1.			Board	T1 Card	Ti Card	T1 Card	T1 Card	T1 Card	T1 Card	T1 Card	T1 Card	T1 Card	T1 Card	Ti Card	T1 Card	T1 Card													
Trunk Monitor			Slot	14	14	14	14	14	14	14	14	14	14	14	14	14	14	14	14	14	14	14	14	14	14	14	14		

FIG. 17B

	1. n . 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1		., 1, 1		
3		ling 	Polling Intervals (in secs):	secs): [1	
•	Refresh on Demand	par	Refresh		
Board	Port	Admin	Auto Partition	Link	_
Ethernet Hub Card	15	Enabled	No	No Link	4
Ethernet Hub Card	16	Enabled	No	No Link	1
Ethernet Hub Card	17	Enabled	No	No Link	Т
Ethernet Hub Card	18	Enabled	No	No Link	T
Ethernet Hub Card	19	Enabled	No	No Link	1
Ethernet Hub Card	20	Enabled	No	No Link	T
Ethernet Hub Card	21	Enabled	No	No Link	Τ
Ethernet Hub Card	22	Enabled	No	No Link	1
Ethernet Hub Card	23	Enabled	No	No Link	1
Ethernet Hub Card	24	Enabled	No	No Link	1
Resource Switch C	1	Enabled	No	No Link	\perp
Resource Switch C	2	Enabled	No	No Link	T
Resource Switch C	3	Enabled	No	Link	_ <u>-</u>
Resource Switch C	4	Enabled	No	No Link	
Resource Switch C	5	Enabled	No	No Link	
Resource Switch C	9	Enabled	No	No Link	- T
Resource Switch C	7	Enabled	No	No Link	
Resource Switch C	80	Enabled	No	No Link	==
Resource Switch C	6	Enabled	No	No Link	Ē
Resource Switch C	10	Enabled	No	No Link	
Resource Switch C	11	Enabled	No	No Link	1
Resource Switch C	12	Enabled	No	No Link	•
			6	Done Help	

FIG. 17C



Extension State Other Party Display Name Card Port Chillook Active Offhook Active Default 0 0 S72 Phone is not op Default 0 0 100 Idle Default 0 0 101 Idle Default 0 0 103 Idle Default 0 0 104 Idle Default 0 0 105 Idle	Link Monitor						
State Other Party Display Name Card Port ook Active Default 0 0 ook Act		0	Use Periodic Poll		olling Intervals	(in secs):	
State Other Party Display Name Card Port ook Active Default 0 0 ook Acti		•		pu	Refresh		
ook Active Default 0 0 ook Active Default	Extension	State	Other Party	Display Name		Port	
ook Active Default 0 0 e is not op Default 0 0 e is not op Default 0 0 Default 0 0 0		Offhook Active		Default	0		•
ook Active Default 0 0 e is not op Default 0 0 e is not op Default 0 0 Default 0 0 0 Default		Offhook Active		Default	0	0	I
ook Active Default 0 0 e is not op Default 0 0 e is not op Default 0 0 Default 0 0 0 Default <td< td=""><td></td><td>Offhook Active</td><td></td><td>Default</td><td>0</td><td>0</td><td></td></td<>		Offhook Active		Default	0	0	
ook Active Default on the pool of the pool of Active Default on the pool of the pool of the pool of Active Default on the pool of the po		Offhook Active		Default	0	0	_
ook Active Default 0 0 e is not op Default 0 0 e is not op Default 0 0 Default 0		Offhook Active		Default	0	0	_
ook Active Default 0 0 e is not op Default 0 0 e is not op Default 0 0 Default 0 0 0		Offhook Active		Default	0	0	
ook Active Default 0 0 0 0 0 ook Active Default 0 0 0 0 0 ook Active Default 0 0 0 0 0 e is not op Default 0 0 0 0 0 e is not op Default 0 0 0 0 0 e is not op Default 0 0 0 0 0 Default 0 0 0 0 0 0 0 Default 0 0 0 0 0 0 0 Default 0 0 0 0 0 0 0 Default 0 0 0 0 0 0 0 Default 0 0 0 0 0 0 0 Default 0 0 0 0 0 0 0 Default 0 0 0 0 0 0 0 Default 0 0 0 0 0 0 0 Default 0 0 0 0 0 0 0		Offhook Active		Default	0	0	-
ook Active Default 0 0 ook Active Default 0 0 e is not op Default 0 0 e is not op Default 0 0 Default 0 0 0		Offhook Active		Default	0	0	_
ook Active Default 0 0 e is not op Default 0 0 e is not op Default 0 0 Default 0 0 0		Offhook Active		Default	0	0	
e is not op Default		Offhook Active		Default	0	0	_
e is not op Default Defau	571	Phone is not op		Default	0	0	
Default 0 0	572	Phone is not op		Default	0	0	
Default 0 0 0 0 0 0 0 0 0	100	Idle		Default	0	0	
Default 0 0	101	Idle		Default	0	0	Ι
Default 0 0	102	Idle		Default	0	0	
Default 0 0 0 0 0 0 0 0 0	103	Idle		Default	0	0	-
Default 0 0 0 0 0 0 0 0 0	104	Idle		Default	0	0	
Default 0 0 0 0 0 0 0 0 0	105	Idle		Default	0	0	1
Default 0 0 0 0 0 0 0 0 0	106	Idle		Default	0	0	
Default 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	107	Idle		Default	0	0	1
Default 0 0 0 0	108	Idle		Default	0	0	
Done	109	Idle		Default	0	0	•
Warning. Annlet Window	_						
	Warning. Annlet	Window					Ī

FIG. 17D

OIPE CON OS 2007

Remote Trace Monitor	
09/11/98 10:45:05:011 NwModule==> InServiceAck - CM = 808AFADO, Streamchan = 00008500 09/11/98 10:45:05:011 NwModule==> Receiving Thread Msg ==> Type (17) From (2) to (3) 09/11/98 10:45:05:011 NwModule==> InServiceAck - CM = 808AFAE8, StreamChan = 00008501 09/11/98 10:46:21:341 cm==> Database Inconsistency - StreamChan = 0000000c Not Configured 09/11/98 10:46:21:411 cm==> Database Inconsistency - StreamChan = 0000000c Not Configured	
	A
Stop Suspend Search Options	
Tracing in Progress	

FIG. 17E



Trace Categories Available	Seld CT Fra	me Relay
		X
	J	

FIG. 17F



Standard Available Categori Component AAServer CDataRep CTICS Connection Manager DSP Manager	Advanced es and Filters Trace Filters Server Remove Clear
Selected Categories	OK Cancel

398

FIG. 17G



Real-7File	ime				
	of Entries D	isplayed -			
500	1000	15	00	2000	2500
Poll Inter	val in Secon				
0	1	$\frac{1}{2}$	3	1 4	1 5
	ch Paramete me				
YYYY 1998 ▼	MM	DD 01▼	HH 12 ▼	MM 00 ▼	SS 00 ▼
– End Tin	ne —				
YYYY 2001 ▼	MM 12 ▼	DD 31 ▼	HH 23 ▼	MM 59 ▼	SS 59 ▼

399 —

FIG. 17H







FIG. 18











FIG. 20







InstantOffic	ce OfficeComm	unicator		
File View (Call Control	Dial Pad	Help	
Messages Transfer Hold Hangup Join	Calls: Calls: Line 1 Line 2 Line 3		0	onsoleActive 0:00 0:00
Net Msg Call Log Config. Help ?	Directory I Dial Pad Feature System Contacts Conference	isting: Type 1 1 2 ASC 4 5 MM 7 8 NOME 1 0 0000 0000 0000 00000 00000 00000 00000	Name Here 3 0 6 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Call Clear

FIG. 22

	\boxtimes
Туре	Name Here ▼
Mess	age Waiting OFF
	Tim
	141

FIG. 23






FIG. 24






FIG. 25




FIG. 26






FIG. 27




FIG. 28






FIG. 29

OIPE OF THE PROPERTY OF THE PR

🛓 Configure User	\boxtimes
Display Name: Marina Smith	
Extension: 889	496
	504
Overview Telephone Forward	ding Pickup Group
Slot/Ports: Slot 1 (Digital)	Port 9: Marina Smith
Access Profile: Unrestricted	▼
Language: (User System Default)	▼
Telephone Usage O Attendant Telephone O Ring Down Hotline Telephone O Normal Telephone External Caller ID O Use the Default as Configured in Gen O Use this Number O Use the Company's Main Number O Send No Information	neral Settings
	OK Cancel Help
492 —	493 500 502

FIG. 30



🕹 Configure	User			
Display Nan	ne: Marina Smit	h		
Extensio	on: 889			506
Overview	Telephone	Forwarding	Pickup Group	
choices may be li	ne type from the list of mited by the hardware works VN16DDS	f supported telephone ty of the Slot/Port you ha	ypes below. The available ve selected on the Overv	iew tab.
	like to enable the	telephone set?		
type you have sel modify the progra	e from the list below. Sected above. For digital mmable settings on the	telephones the "Custon	e determined by the telepnize" button allows you t	phone o
Featured 512		▼	Customize	-514
Features Do Not 1 Call Wai 516	Disturb			
		OK	Cancel	Help
			93 500	502

FIG. 31




🕹 Configure	User			\boxtimes
Display Nam	ne: Marina Smit	h		
Extensio	n: 99 0			
LAICHSIO	11. 807			
Overview	Telephone	Forwarding	Pickup Group	
Select the telephone choices may be li	ne type from the list o mited by the hardware	f supported telephone ty of the Slot/Port you hav	pes below. The available we selected on the Overview tab.	
Vertical Netw	vorks VN16DDS			
Would you	like to enable the	telephone set?		
o Yes		1		
● No				
type you have sele	e from the list below. ected above. For digital mmable settings on the	telephones the "Custom	e determined by the telephone ize" button allows you to	
Featured		V	Customize	
Basic				
DSS/BLF				
Featured Retail				
Retail 2				
Secretarial				
Secretarial 2				
[(None)				
		OK	Cancel Help	

512-

FIG. 32



FIG. 33



1









FIG. 35





Feature: Primary		
Telephone Number:	_	
Additional Settings		561
☐ Do Not Ring the Telephone		
☐ Do Not Receive Paging		
☐ OffHook Ring		
✓ Mute Microphone when Voice Calls are Rece	eived	
		
	OK	Cancel

FIG. 36



Edit Global Access Profile ~ 574 Access Profiles	
Status	Name
	Default Modems System Ports
572	Edit New Delete Copy
Restore	Apply Done Help

570

FIG. 37



rea Code Table	Off Premise Extension Table	Special Digits Table
Initial Digi	ts Routing Table	Intercept Target
911 5853204	Route 2 Intercepted> Intercepted> *Blocked* Route 2 Route 1 (New Routing Table)	550
	Edit Routing Table	New Delete

FIG. 38A



lame: Default		
Area Code Table	Privileges Trunk Group	Access Codes
Area Code	Office Code Range	Routing Table
212	Default	Local Calls
408	Default	Acme West
Default	Default	*Blocked*
		Blocked
		Acme West
		3xx Offpremise
		Modems Route
4		Local Calls
	Edit Routing Table	(New Routing Table) New Delete
		OK Canc

FIG. 38B



a Code Table Off Premise Ex	tension Table Special Digits Table
Extension Range	Routing Table
300-399	3xx Offpremise

FIG. 38C



ame: Default				
Area Code Table	Privileges	Trunk Group	Access Codes	
Area Code	Office	Code Range	Routing Table	
212	Default		Local Calls	
408	Default		Acme West	
Default	Default		*Blocked* ▼	
			Blocked	
			Acme West	
			3xx Offpremise	
			Modems Route	
◀			Local Calls	
			(New Routing Table)	
	Edit R	outing Table	New Delete	

FIG. 39A



🕹 Access Profile
Name: Default
Area Code Table Privileges Trunk Group Access Codes
International (011) Routing Table: *Blocked*
Edit Routing Table
Carrier Access Code Destination: T1 Interface 1
OK Cancel

FIG. 39B

	ne: Default		
Ar	rea Code Table	Privileges	Trunk Group Access Codes
	Access	Code	Permission Allowed
	83 80 82 84 81		
			OK Cancel

FIG. 39C



sep			Strip First Keep Last Prepend Postpend Destination Service Up Digits Digits Digits Digits Code Noice Analog Strip First Keep Last Digits Down Code Digits Down Took Down Took Down Took Digital Down Woice Analog Voice Analog	OK Cancel
	A Routing Table	Name: Local Calls	ts a	

FIG. 40

First Digit Table		\boxtimes
First Digits Local	ocal Area Codes	
Digit (Type)	Digit Type: External	>
0 (Attendant)	Additional Settings	
1 (Extension)	○ One-Digit © Two-Digit	
2 (Extension)	Access Code Routing Collect Digits	its Dialtone
(TOYOTOTI)	80 T1 Interface 1 3	□.
4 (Not Configured)		
(Fytension)		S
(EACHSIOH)		S
6 (Not Configured)	Outbound Routing	⊠
7 7 7 7		
/ (Not Configured)	86 Not Configured 5	
8 (External)		Ŋ
	88 Not Configured 7	
9 (External)	89 Not Configured 8	S
-	6	
	10	
	17	<u> </u>
	Restore Apply D	Done Help
]]]

FIG. 41



			Remove					Restore Anniv Done Hein
First Digit Table	First Digits Local Area Codes	Local Area Codes	Add	1212 212		Home Area Code: 212		

FIG. 42



eneral Settings		
Voice Mail (Limits)	Voice Mail (Interacti	ion) Fault Monitor
System	PBX	PBX (Advanced)
Audio ————————————————————————————————————		
External Caller ID Prefix Digits: 40	20222	
O Company Name	ller ID Format (for call and Main Number d Prefix Digits + Exten	• ,
	Restore	Apply Done Help

FIG. 43A




Name: T1 Interface 1	
Direction: ○ In ○ Out ● Both	
In Out	
Caller ID Format	
 Send Internal Caller ID (as received in tandem calls) Send External Caller ID (as received in tandem calls) Send Company Main Number Do Not Send Caller ID 	
Hunt Type	
● Linear ○ Circular	
OK (Cancel

FIG. 43B

01P &

& Configure Station	\boxtimes
Extension: 200	
Display Name: Station 200	
Overview Features Forwarding Pickup List	
Card/Port: Slot 1 ▼ Port 1: Station 200	▼
Access Profile: Default	▼
Language: English (United States)	▼
O Attendant Phone	
O Ring Down/Hotline	
O Neither	
External Caller ID	
 Use the default as configured in General Settings 	
O Use this number:	
O Append extensions to the default DID pattern	
Use the company's main number	
○ Send no information	
OK Car	ncel

FIG. 43C



Propagation 5 ms

FIG. 44








FIG. 45





3 Kou Name	ting Tabl : To Mu		·				<u> </u>
· · · · · · · · · · · · · · · · · · ·	. 10 1414	Stang				· ,	
Step	Strip First n Digits	Keep Last n Digits	Prepend Digits	Postpend Digits	Destination	ISDN Settings	Up
1	0				IP Mustang	N/A	Down
2	0				Voice Digital		
3	0				Voice Analog		


FIG. 46C



FIG. 47A

Extension to external telephone (toll bypass)

Extension to extension (Uniform Dialing)









FIG. 47B










FIG. 48B






FIG. 48C






FIG. 48D







FIG. 48E








FIG. 49A

FIG. 49D




FIG. 49B

